LFT40 PENDANT MOUNT INSTALLATION

LFT-T-01





INSTALLATION INSTRUCTIONS

Please note that these steps can be used for installation and/or bulb replacement instructions, and it is recommended that these products are installed by a qualified electrician.

- 1. Prior to installation, ensure that the power supply is switched off.
- 2. Follow each step by referencing the images as seen in this guide.
- 3. After completing each step, ensure that screws are tighten to the fixture, then proceed to connect to power supply.


TRACK SECTION





Article Number (L)

LFT-T-01-44 44.57" (1132 mm) LFT-T-01-89 89.13" (2264 mm)



SKU: LFT-T-03 Type: 7 Type vertical corner

ACCESSORIES



2PCS


SKU: LFT-NR-01 Type: Trimless bracket



SKU: LFT-NC-02

Type : Surface mounted & Pendant reinforced

plate




SKU: LFT-T-02 Type: L Type horizontal




SKU: LFT-NC-01

2PCS



LFT-NE-01-11 11.14" (283 mm) LFT-NE-01-22 22.28" (566 mm)

Type: Blank cover



9.06"

(230 mm)

3.42 (87 mm) SKU: LFT-T-04 Type: T Type horizontal connector



Type: End cap

SKU: LFT-DI-15 Type: Pendant Kit for power

connection (without power cord)



SKU: LFT-DI-15-V Type: Pendant Kit for power connection (without power cord and signal wire)





SKU: LFT-DI-16 Type: Pendant kit



SKU: LFT-NC-06

Type: Light Leak-proof aluminium extrusion reinforce plate

1.61"

(41 mm)

9.06"


(230 mm)


LFT40 PENDANT MOUNT INSTALLATION


LFT-T-01




INSTRUCTIONS (1 OF 3)











LFT40 PENDANT MOUNT INSTALLATION


LFT-T-01




INSTRUCTIONS (2 OF 3)









LFT40 PENDANT MOUNT INSTALLATION

LFT-T-01



INSTRUCTIONS (3 OF 3)

